



123456789101112131415161718192021222324252627282930313233343536373839404142434445464748495051525354555657585960616263646566676869707172737475767778798081828384858687888990919293949596979899100

123456789101112131415161718192021222324252627282930313233343536373839404142434445464748495051525354555657585960616263646566676869707172737475767778798081828384858687888990919293949596979899100
 [succulents](#)

- PP,
- .
-
-
-
-
-

123456789101112131415161718192021222324252627282930313233343536373839404142434445464748495051525354555657585960616263646566676869707172737475767778798081828384858687888990919293949596979899100
 Succulent Pot

123456789101112131415161718192021222324252627282930313233343536373839404142434445464748495051525354555657585960616263646566676869707172737475767778798081828384858687888990919293949596979899100
 [succulents](#)



RDZ90A

Item	Models	Top Dia mm	Bottom Dia mm	Height mm	Weight g/pcs ±3%	QTY /carton	Weight kg /carton	Package size(mm)
Succulent pot	RFZ70	70	50	75	10	1500	15.0	48×36×36
	RFZ80	80	60	90	15	1125	16.9	48×36×36
	RFZ90	90	65	100	20	800	16.0	48×36×36
	RFZ100	100	75	110	24	640	15.3	48×36×36
	RFZ100A	100	75	110	24	640	15.3	48×36×36
	RDZ65	65	52	65	6	1500	9	40×35×35
	RDZ70	70	50	75	10	1500	15.0	48×36×36
	RDZ90A	90	65	100	20	800	16.0	48×36×36

Hard PP material, adding toughening agent, long service life, used to place tissue culture box



Item	Models	Top Dia mm	Bottom Dia mm	Height mm	Weight g/pcs ±3%	QTY /carton	Weight kg /carton	Package size(mm)
Succulent bracket	TRZ30	67	55	65	520	25	13.0	49.5×43×42
	TRZ40	40	55	53	325	25	8.1	

Succulent